

# 用電安全小貼士



## ELECTRICAL SAFETY TIPS



1. 必須使用符合安全規格的插座、三腳插頭、萬能插或拖板，並使用電壓為230伏、頻率50赫茲的電器。

Use sockets, three-pin plugs, adaptors or extension boards that comply with the safety requirements and standard. Use electrical appliances rated for 230V voltage and 50Hz frequency.



2. 切勿在同一插座上使用太多插頭。每個插座只可插上一個萬能插或一個拖板，切勿在拖板上使用萬能插，以免電力超出負荷。

To prevent circuit overload, do not insert too many plugs into a socket outlet. No more than one adaptor or one extension board should be inserted into a socket outlet. Do not plug the adaptor into the extension board.



6. 不可同時使用高負荷的電器，如：電熱水壺、風筒及暖爐。

Do not use high wattage electrical appliances such as electric kettles, hair dryers and heaters at the same time.

3. 切勿拉扯電器的軟電線以拔出插頭，以免損壞插頭接線，造成危險。

Do not unplug an electrical appliance by pulling its flexible power cord as it may damage the wire connection and cause danger.



4. 手濕時切勿觸碰任何電器、插座或電掣。

Do not touch any electrical appliances, sockets or switches with wet hands.


5. 切勿使用破損電線或破裂的插頭。應檢查所有電源線，確保狀態良好，並沒有任何部分損毀、撕裂、破裂或磨損。

Do not use damaged cords or plugs. Ensure all cords are in good conditions and no part of the cable is worn, split, cracked or frayed.



7. 為安全起見，外出前應盡可能將所有電器關掉。

For safety, electrical appliances should be switched off as far as practical before going out.



8. 若使用電器時發現不正常或過熱情況，應立即停止使用，關掉電源及安排合資格人員檢驗及維修。

If appliances operate abnormally or if there are signs of overheating, stop using the appliances. Switch them off and arrange for inspection and repairs by qualified persons.

9. 電池充電時間不應太長，避免無人在家時充電。

Battery charging time should not be too long. Avoid charging while no one is at home.



資料來源：  
香港職業安全健康局，香港機電工程署，澳門電力股份有限公司  
Sources:  
Hong Kong Occupational Safety and Health Council  
Hong Kong Electrical and Mechanical Services Department  
Companhia de Electricidade de Macau